

# HOUSEPURE®

9100TS

## QUICK START




Figure 5

1. **SET.** Used to accept a setting that normally becomes stored in memory. Also used together with the arrow buttons.
2. **DOWN arrow.** Generally used to scroll down or decrement through a group of choices.
3. **UP arrow.** Generally used to scroll up or increment through a group of choices.
4. **REGENERATE OR EXTRA CYCLE.** Used to command the controller to regenerate.



**INSTALL 9100TS ACCORDING TO MANUAL AND LOCAL PLUMBING CODES**

**SLOWLY TURN ON INCOMING SIDE OF BYPASS**

**WAIT FOR WATER TO FILL TANK AND AIR TO STOP**

**PUSH AND HOLD “REGENERATE” TO START CYCLE**

**IMMEDIATELY AFTER THE VALVE STARTS –PUSH AND HOLD THE “SET” AND “UP” BUTTONS**

**THE “HOUR GLASS” ICON WILL START FLASHING**

**THE VALVE WILL NOW CYCLE THROUGH TO THE END WITHOUT STOPPING**

**REPEAT TWICE ON EACH TANK**

**ADJUST HARDNESS SETTING**

**OPEN OUTGOING SIDE OF BYPASS VALVE**

**CHECK FOR LEAKS**

**ADD SALT TO THE BRINE TANK**

