



EVERCOLD® INSTANT CHILLED WATER SYSTEM Model WI-WIC400S

INSTALLATION INSTRUCTIONS

Contents:

- 1 – EverCold® Water Chiller
- 1 – Insulation Sleeve

**STOP – CHILLER MUST BE IN UPRIGHT POSITION FOR 3
HOURS
PRIOR TO INSTALLATION OR DAMAGE MAY OCCUR.**

1. This unit is intended to be installed underneath a residential sink in a cabinet not less than 36" wide (inside dimension). To improve chilling performance, two air openings with a minimum of 4 square inches each, should be provided in the cabinet. One opening should be in the overhang of the toe space, the other opening near the top of the cabinet. The unit must be installed with a minimum of 3 inches clearance between the unit and the sidewalls of the cabinet.
2. Fittings Installation: **NOTE:** Fittings have been factory installed for you. Do not remove them or change to a different type as warranty will be voided.
3. Connect chiller to water supply: Install a 1/4" water line (use polyethylene, polypropylene, or nylon tube; **DO NOT USE VINYL TUBING**) from a shutoff valve or filter system (not supplied) to chiller inlet. Tubing must be cut squarely and inserted fully into fitting.
4. **NOTE:** You **MUST** relieve water pressure in the chiller before turning it on. Connect 1/4" water line from outlet to accessory faucet. TURN ON THE COLD SIDE FAUCET. This will purge the air from inside the chiller tank as it fills with water. Failure to open the faucet could cause damage to the unit. Slide insulation sleeve over water line before making final connection.
5. Water temperature control has been set mid-way on number 4. To avoid any possible leaks caused by the chiller freezing up, we strongly suggest that you adjust the temperature slowly to a colder setting. Too cold an adjustment could cause a leak. A conservative approach would be to turn the cold control knob clockwise, one digit at a time. Wait 3 hours before adjusting it to a colder setting.

For service questions, call (800) 322-9283 ext. 112 or 115

EverCold® WI-WIC400S

Undersink Water Chiller

PLEASE READ THIS NOTICE

The cold control setting on this chiller has been set mid-way at number 4, for safety reasons. You may find that the water is not cold enough for you.

In order to avoid any possible leaks caused by the chiller freezing up, we suggest that you adjust the temperature slowly to a colder setting. Be aware that too cold an adjustment could cause a leak!

A conservative approach would be to turn the cold control knob clockwise, one digit at a time. Wait 3 hours before adjusting it to a colder setting, assuming you are still not satisfied with the temperature.



WaterInc

For service questions, call:
(800) 322-9283 ext. 112 or 115